

## **ESTENAD WORKSHOP**

## **AUTONOMOUS MAINTENANCE PROCESS**

Make			DAILY	MONTHLY
Model				
S/N		CUTSO CUTSO		
Equip	Plasma Cutting Machine			
Sr. No.	Activity / Check List		Responsibility	Instructions
1	Area of Operation		Operator	Machine and area around the machine is clean safety covers are in good condition
2	Torch Main Body		Operator	Inspect threads, water tube, anode current contact ring, head-to-head torch QD connections and replace if necessary
3	Gas console and Hoses		Operator	Check the health of gas hoses and replace if necessary
4	Connection Check	_	Operator	Check the terminals for any looseness. As loose terminal connections may cause spark

5	Voltage & Amp. Gauges	Operator	Check the voltage and Amperage gauges are working properly
6	General Inspection	Operator	Check the machine is in good condition
7	Cleaning	Operator	Direct airflow through louvers or blow out or vaccum inside
8	Torch components and hose    Solver   State   State	Operator	Inspect threads, water tube, anode current contact ring, head-to-head torch QD connections,hoses and replace if necessary
9	Power connections	Operator	Check the electric connection is in good condition
10	Cables and Cords	Maintenance	Check the condition of cables and cords. Repair or Replace if necessary
11	Damaged Parts	Maintenance	Replace the damaged parts if any
12	General Cleaning	Maintenance	Direct airflow through louvers or blow out or vaccum inside